

# Association of Australasian Acoustical Consultants Licensed Premises Noise Assessment Technical Guideline

Version 1.0



Photo by Patrick Tomasso on Unsplash

## TABLE OF CONTENTS

<b>1</b>	<b>Introduction .....</b>	<b>3</b>
<b>2</b>	<b>Patron Sound Levels.....</b>	<b>3</b>
2.1	Overview.....	4
2.2	Computational Methods.....	4
2.3	Venue Patron Levels .....	5
2.4	Open Air Gaming Areas .....	6
2.5	Semi-Enclosed (e.g. Smoking Areas).....	7
2.6	Outdoor Areas (e.g. Beer Gardens).....	7
<b>3</b>	<b>Live Music / Nightclub Internal .....</b>	<b>7</b>
3.1	Recommended Approach to Noise Limiters .....	8
<b>4</b>	<b>Appendix A: Rindel Method .....</b>	<b>10</b>
<b>5</b>	<b>Appendix B: Talker Data.....</b>	<b>11</b>
<b>6</b>	<b>Appendix: References .....</b>	<b>13</b>



*Photo by Vishnu R Nair on Unsplash*

## 1 Introduction

The potential impacts of noise from the operations of licensed premises needs to be carefully addressed by relevant regulatory authorities to balance the needs of our society for entertainment and socialising and the desire for reasonable levels of amenity in the surrounding community.

This Technical Guideline has been drafted based on the collective experience of AAAC member firms. The different States and Territories within Australia have quite different criteria in relation to noise from licensed premises, so this Guideline specifically excludes discussion around the appropriateness of criteria. It is possible AAAC member firms in each State, may produce an Appendix to this Guideline if they feel consensus is met within the State.

Noise from licensed premises can be broken down into the following main categories:

- Patrons and music within the premises (both internal and external).  
Whilst music noise can be appropriately controlled, patron noise depends on a number of factors.
- General operational noise such as cleaning, clearing of glass bottles, garbage collection, deliveries
- Patron and vehicle noise from "on-site" car parks
- Patrons in the public domain in close proximity to the premises as they leave (wait for taxis) and in surrounding streets walking to parked cars, public transport or home
- Mechanical plant such as air-conditioning and kitchen exhaust fans during operating hours and refrigeration equipment (24 hours)

We consider that the assessment of "off-site" noise is best handled by planners, as it is clear that unruly, loud behaviour of patrons and noise from car-doors and engines late at night have the potential to cause disturbance. However, these are lawful activities which could similarly result from any visitors to private gatherings in a residential street, or patrons who have visited other licensed premises.

In addition, the assessment of general operational noise, noise from patrons and cars in car parks can be addressed in accordance with other relevant guidelines which apply to the operation of any business.

This Technical Guideline therefore provides information to cover two key areas:

- Patron sound level data which will be useful in predicting noise emissions from groups of people in various situations including, restaurants, small outdoor drinking/smoking areas, poker machine areas, beer gardens and nightclubs.
- Typical music sound level data within venues and measures to minimise and limit music noise breakout.
- It encourages operators of licensed premises to seek the advice of specialists and tries to address the "louder is always better" approach which seems to have prevailed for many years.

Investment in high quality equipment, design of spaces, and construction materials can result in a better experience for venue patrons listening to music, a better experience for those in other parts of the venue and better amenity for residents living nearby.

## 2 Patron Sound Levels

This section provides a summary of existing research, suggested prediction methods and recommendations for further investigations. A Technical Appendix is also provided which includes more detailed discussion.

## 2.1 Overview

In many areas within licensed premises and eating establishments in which people are gathered to socialise, noise levels from conversations can often be elevated due to the noise-begets-noise phenomenon. These elevated levels are associated with the Lombard effect and are due to a combination of the number of people talking, the style of gathering and the local acoustic environment in which the people are gathered. In addition to the noise-begets-noise mechanism, loud levels can also be produced by exuberant people talking loudly to simply make a point.

Five main categories of use are considered.

- Predominantly internal areas; e.g. restaurants or bars
- Small semi enclosed or outdoor areas; e.g. smoking terraces/areas
- Outdoor gaming rooms
- Medium to large semi-enclosed or outdoor areas; e.g. beer gardens

The consumption of alcohol has the potential to increase level of crowd noise as people lose their inhibitions and become more boisterous. Although laboratory data shows that the voices of females are 3 dB less than males, field experience indicates that groups of females who are partly affected by alcohol often make more noise as individuals than males, due to their exuberance.

In outdoor drinking areas in hotels, the use of security guards to manage any unruly behaviour and avoid noise disturbance is sometimes proposed. However, this can lead to difficulties in some situations with guards having to draw the line between appropriate and inappropriate behaviour. One example is where a large number of people are all behaving well, but speaking in raised voices, while another example is where a few people are simply raising their voices in animated conversation. Although both these situations represent appropriate behaviour, they have the potential to cause noise disturbance.

To date, prediction of patron noise levels has often been made by simply assuming that patrons speak with a raised voice and adjusting the level for the number of talkers  $N$  on the basis of  $10\log N$ . However, this method can be inaccurate with groups of people as it does not account for the Lombard effect in human responses to noise. The Lombard effect is the involuntary tendency of talkers to increase their vocal effort when speaking in a noisy environment to enhance the audibility of their voice.

Accurate prediction of the noise levels produced by patrons enables the following:

- accurate prediction of noise breakout from semi-enclosed dining/drinking/smoking
- the acoustic comfort of patrons with respect to ease of conversation or elevated sound levels
- the degree of speech intelligibility perceived by listeners

## 2.2 Computational Methods

There is no perfect approach to predict noise from licensed premises. An acoustical consultant should consider each situation and advice the most appropriate approach.

One method incorporates the Lombard ratio in the calculation of talker levels. The Lombard ratio is the ratio of the decibel increase of a talker's speech level relative to the increase in the level of ambient noise in which the talker is immersed. An important feature associated with the use of the Lombard ratio is that it is based on talkers attempting to maintain verbal communication in the presence of noise.

The method proposed by Rindel provides a method to predict noise from talkers in semi-enclosed and enclosed spaces. The size of the speaking group and reverberation time of the space are determined and combined with the Lombard ratio to predict the level of noise in the space. The major uncertainty in Rindel's method is the size of the speaking group and correct value of the Lombard Ratio to use.

Rindel recommends a Lombard ratio of 0.5, which equates to 0.5 dB per 1 dB increase in the ambient level and produces a 6 dB increase in internal sound level for every doubling of the number of people talking simultaneously. This result contrasts with the usually accepted rule of 3 dB increase per doubling of talkers. A large study of talkers conducted in 1977 by Bolt Beranek and Newman concluded people increase their speech at the rate of 0.6 dB per 1 dB increase in the ambient level. Haynes et al present a list of ratios used by various researchers showing ratios ranging from 0.2 to 1.

Rindel states that the method is validated only for more than 50 people, however comparison of measured and predicted levels for two groups of 8+ people by an AAAC Member Firm in a number of semi-enclosed and closed environments has shown good similarity between measurement and predictions. The method is not recommended for sporting crowds with cheering noise, as cheering involves other human factors besides the Lombard effect.

The primary equations underpinning this method are given in Appendix A. Pertinent aspects of the method are:

- Although Rindel's equations are based on A weighted levels, the method can be adapted to yield octave and third octave band spectral levels in the patron area.
- The spectrum associated with the vocal effort used by patrons should be selected according to the computed talker level; i.e. normal, raised and loud voice.
- The Eyring equation should be used to compute the reverberation time of the unoccupied space.

In applying the method, it is critical you understand the proposed use of the space, expected reverberation times, reflective surfaces. The presence of background music and the fact that its level can be readily adjusted significantly complicates the noise-begets noise mechanism and needs to be dealt with on a case-by-case basis. Given that complexity, it is not covered in this document.

The consumption of alcohol has the potential to increase level of crowd noise as people lose their inhibitions and become more boisterous. Although the measured data shows females voices to be 3 dB softer than males, field experience indicates that groups of females in pub situations can produce higher levels than males due to animated and exuberant conversations.

### **2.3 Venue Patron Levels**

To assist users of this guide, Table 1 presents predicted  $L_{Aeq}$  levels within the patron area for seventeen situations, ranging from small semi-enclosed areas to large bars and restaurants, with a variety of patrons. Also given are the sound power level ( $L_{WA}$ ) produced by an individual talker acting under the Lombard effect, and various room acoustic details.

For these examples the predicted levels in Table 1 were computed with the following parameters, all of which could change to suit a particular venue:

- The speaking group size of 3, meaning that one in three people is talking simultaneously.
- The spectrum of the speech was adjusted according to the vocal effort required in accordance with the Lombard ratio of 0.5.
- The reverberation times are for an unoccupied space with the assumed relative reverberation times in octave bands shown in Table 2.
- The spaces are modelled using the Eyring method.
- The unoccupied reverberation times were adjusted according to the absorption of patrons who are assumed to occupy 70% of the floor area. Adjustments must be made using the area of patrons, and not on a per-person basis.
- Talkers are assumed to be evenly distributed over the floor.

- The direct field of the talkers in the patron area was calculated as a spatially-averaged level using numerous talker and listener locations selected at random. Talkers were assumed to face in different directions and with losses due to directivity. The direct and reverberant fields were then summed. (Although the level of the direct field varies with selected positions, it is sufficiently small to not significantly affect the overall level.)
- The calculations were made in octave bands using the talker data given in Appendix B.

Readers can also calculate the levels using fundamental acoustic principles, based on a given number of talkers, selected Lombard ratio, reverberation times, size of space, distance attenuation and acoustic shielding etc. It is recommended that the calculations be made on an octave-band basis, as this produces results that match measurements over a wide range of situations.

**Table 1 – Estimated noise levels produced by talking patrons**

Scenario	Volume m <sup>3</sup>	RT (sec) without patrons*	No of Patrons	Assumed Floor Area m <sup>2</sup>	Assumed Room Height m	Room Constant with patrons* ^	Talker LWA#	L <sub>Aeq</sub> in patron area
A	50	0.3	10	16.7	3.0	47	78	74
B	50	0.6	10	16.7	3.0	25	81	79
C	100	0.5	10	33.3	3.0	62	77	71
D	100	0.8	15	33.3	3.0	43	81	78
E	100	0.5	20	33.3	3.0	62	80	78
F	100	0.8	20	33.3	3.0	43	82	80
G	150	0.7	30	45.5	3.3	70	81	80
H	150	1.0	30	45.5	3.3	54	82	82
I	150	0.7	50	42.9	3.5	68	84	84
J	150	1.0	50	42.9	3.5	52	85	86
K	250	0.8	50	71.4	3.5	107	82	80
L	250	1.3	50	62.5	4.0	70	84	84
M	250	0.8	100	62.5	4.0	100	85	87
N	250	1.3	100	62.5	4.0	70	87	90
O	300	0.8	100	75.0	4.0	122	84	85
P	300	1.3	100	75.0	4.0	86	86	88
Q	400	1.8	200	100.0	4.0	96	88	93

\* averaged over range from 250 Hz to 2 kHz; ^includes and estimate of the sound absorption produced by patrons; #the sound power level of one third of the total patrons in the space who are speaking.

**Table 2 - Relative reverberation times used for calculations in Table 1**

Frequency Hz	125	250	500	1000	2000	4000	8000
Relative RT	1	1.1	1.1	1	0.9	0.8	0.6

## 2.4 Open Air Gaming Areas

Open-air gaming areas have become ubiquitous in licensed premises since the introduction of the Smoke-free Environment Regulation 2007 and have subsequently resulted in many noise assessments for such areas.

Noise emissions are commonly predicted by determining internal reverberant noise levels based on published speech levels and subsequent breakout to receivers. The challenge lies in choosing a representative vocal effort and quantity of speaking patrons. Gaming lounges can often be very quiet where gamblers are individually immersed or conversely, small groups can be gregariously huddled around machines. In these situations, the Lombard effect is likely to not occur and therefore Rindel method should probably not be used.

Noise emissions from the machines themselves can be manually adjusted by staff and thus it is conservatively assumed that patron noise takes precedence.

## **2.5 Semi-Enclosed (e.g. Smoking Areas)**

Semi enclosed areas for drinking, smoking or dining can range from small to large. There is considerable diversity in the way that people engage with dedicated smoking areas. Some venues have low capacity areas with patrons engaging in minimal, casual conversation, while others are places for people to sit, drink and converse, many without smoking. While some areas are overseen by a security guard, many are not. In many smoking areas, the area is partly enclosed, often by a rear wall, floor and ceiling, and this enclosure renders the acoustic environment partially reverberant. Reflections therefore can play an important role in determining the overall sound pressure levels in the area.

Rindel's method is able to model Scenarios A to E in Table 1 and can be representative of small semi-enclosed areas, particularly as animated conversations can occur in these areas when a number of people are gathered.

## **2.6 Outdoor Areas (e.g. Beer Gardens)**

The prediction of source noise levels of medium to large outdoor areas (e.g. 20-200 patrons) remains the least conclusive area of research. Crowd noise levels do not always appear to be directly related to crowd size, and the presence of alcohol or a celebratory atmosphere are likely to be important factors.

Research in this area has been undertaken by acoustic professionals including AAAC Member Firms listed in the bibliography.

The research has shown that noise levels are not directly related to crowd sizes, particularly for larger numbers. The area occupied by the crowd and distance from the venue will require different adjustments in each situation. An Acoustical consultant will need to assess each situation carefully in order to determine noise egress.

## **3 Live Music / Nightclub Internal**

These venues are dominated by music rather than patron noise and would often use an appropriate noise limiter to manage noise levels. Where the venue is in a building separated from the nearest noise-sensitive receiver, low frequency noise and breakout through windows and the roof need to be considered. In addition, where the venue is in the same building as noise-sensitive receivers, structure-borne noise needs to be considered. These are both complex acoustical issues which will require the input of an acoustical consultant.

Although these spaces are normally considered to be fully enclosed, noise escaping through external doors that are temporarily opened to allow entry and egress of patrons could be problematic. In these situations, the use of a sound lock should be considered.

Breakout noise from amplified music is a common concern for Councils and a trigger for neighbourhood noise complaints. The primary concern is often low-frequency noise emissions at frequencies typically handled by the subwoofers due to reasons such as:

- ease of transmission through the building structure
- genres of music in nightclubs with high emphasis on bass frequencies,

- a preference for patrons to “feel” the music
- the affordability of powerful sound systems.

Table 1 provides a summary of typical internal reverberant noise levels from amplified music.

**Table 1 Typical Internal Reverberant Noise Levels from Amplified Music**

Type	Internal Level (LAeq)	Comment
Background Music	67-74 dBA	Allows for conversation at normal vocal effort at 600 mm separation.
	70-77 dBA	Allows for conversation at raised vocal effort at 600 mm separation.
Foreground music	85-90 dBA	Minimum level patrons expect amplified music to be played at when the music is meant to be the dominating soundscape (i.e. levels below this would be considered not loud enough.) Typical night club level at the start of the night.
	90-96 dBA 101 to 106 dBZ 100 to 105 dBC	Typical level within a nightclub as patron numbers increase. Loud vocal effort required in close proximity to listener’s ear. Potential nightclub level early in the night when patrons and operators may be suffering from a temporary threshold shift (TTS) <sup>1</sup> in hearing (e.g. after approximately 1 hour of amplified music exposure.)
	97-105 dBA 107 to 115 dBZ 106 to 120 dBC	Typical level that may be considered “very” or “extremely” loud. Loud to shouting vocal effort required in close proximity to listener’s ear. Potential nightclub level towards peak of the night and/or when patrons and operators may be suffering from an even greater temporary threshold shift (TTS) <sup>1</sup> in hearing. The LZeq sound level in the 63 Hz octave band can be as high as 120 dB. Note that the level of programme content in the 31.5 Hz band is increasing and may need to be considered.

Note 1: The temporary reduction in hearing sensitivity due to exposure to very loud sounds.

### 3.1 Recommended Approach to Noise Limiters

It is a common belief that the use of an RMS compressor limiter is all that is needed to control internal sound pressure levels of amplified music in order to limit noise levels at nearby receivers. In their conventional implementation, these devices significantly change the short-term dynamics of the music, reducing its crest factor and often sucking the life out of the music. Bass sounds are often the trigger for the compression process, which can lead to pumping effects or loss of clarity. The ultimate result of this type of sound-level limiting is discontent by venue operators, due to the poor sound quality.

A better approach is to use an automatic long-term RMS leveller, utilising relatively long attack and release time constants. This type of device sets the long-term RMS level of the music to a defined signal level, allowing the peaks to pass mostly unaffected. The target level is adjusted to suit the criteria for a  $L_{eq}$  or  $L_{10}$  level at noise receivers. Although the  $L_{eq}$  level inside the venue may be slightly softer with this approach, this is more than compensated for by the improved sound quality due to the increased dynamics in the music.

The time constants required for this type of level control are not usually found in compressor/limiter devices, and therefore a dedicated long term AGC (automatic gain control) device (implemented in a digital signal processor) is the optimum method of control. The target level can usually also be adjusted according to time of night to meet noise criteria in the post-midnight period.

## 4 Appendix A: Rindel Method

- a) Rindel's equation for the level of ambient noise due to people speaking is:

$$L_{NAeq} = 93 - 20\log(A/N_s) \quad (\text{eq 1})$$

where  $A$  is average absorption area in the space and  $N_s$  is the number of people speaking.

Although  $A$  is equivalent to  $S.alpha$  in Rindel's work, making  $A = \text{Room Constant } (R)$  provides a better match to measured levels in smaller areas.  $R$  is computed from the average reverberation time in the 250 Hz to 2 kHz range, based on the Eyring equation.

- b) Incorporating the concept of a Group Size  $G$ , equation 1 becomes:

$$L_{NAeq} = 93 - 20\log(AG/N) \quad (\text{eq 2})$$

where  $G = N_s/N$  and  $N$  is the total number of patrons.

- c) The level of individual talkers at 1 m is computed as:

$$L_{TAEq} = 55 + L_r(L_{NAeq} - 45) \quad (\text{eq 2})$$

where  $L_r$  is the Lombard ratio of 0.5

- d) As noise criteria sometimes require the use of the  $L_{10}$  level, 3 dB is usually added to the  $L_{eq}$  levels to produce the  $L_{10}$  speech levels.
- e) The calculations can also be done on an octave-band basis, which is the method use to derive the values in Table 1.

## 5 Appendix B: Talker Data

This Appendix includes raw data often used by Acoustical Consultants. Once the operation of the Licensed Premises is understood it can be used to assess noise in almost every situation.

A summary of speech levels often quoted is shown in **Table 1**

**Table 1** Mean vocal effort levels in dB(A) in anechoic conditions, measured at 1 m.

Vocal Effort	Male, dBA @ 1m	Female, dBA @ 1m	Source
Casual	53	50	C.M. Harris
Normal	58	56	Cushing et al
Raised	67	64	
Loud	76	77	
Shout	89	82	

**Table 2** gives the long term octave-band  $L_{Zeq}$  levels at 1 m from a talker on axis of the mouth.

**Table 2** Octave band spectra for Male talker (Cushing et al)

Frequency	125	250	500	1000	2000	4000	8000	Overall dBA	Overall dBZ
normal	46.5	56.4	57.5	52.3	48.3	44.3	38.8	58	61.2
raised	55.8	62.5	65.4	61.7	57.1	52.1	45.9	66.4	69.0
loud	58.5	66.9	73.2	72.3	66.9	61.5	52.9	75.5	77.0

**Table 3** gives the  $L_1$  and  $L_{10}$  exceedance levels in each octave band for normal speech whose long-term  $L_{Zeq}$  level has been normalised to 0 dB. To use these exceedance levels, simply add the levels in Table 3 to the overall  $L_{Zeq}$  of the speech.

**Table 3**  $L_1$  and  $L_{10}$  exceedance levels for normal speech with a long-term overall  $L_{Zeq}$  level of 0 dB.

frequency	125	250	500	1000	2000	4000	8000	Overall $L_{zn}$
average $L_1$	0.8	2.8	1.8	-2.6	-5.0	-6.6	-8.5	5.6
average $L_{10}$	-1.9	-2.4	-2.1	-7.6	-11.5	-11.3	-13.4	3.0

**Table 4** gives approximate directivity indices at each octave band frequency to calculate sound power of talkers.

**Table 4** Approximate directivity indices (DI) for human talker

frequency	125	250	500	1000	2000	4000	8000
DI dB	1.2	1.9	1.6	1.8	3.4	4.2	4.6

In some situations, it can be useful to account for directional losses of the human voice associated with the directions that talkers are facing in a venue. **Table 5** gives normalised approximate total direct-field sound pressure levels in each octave band frequency for a group of talkers who are equally distributed around 360°, relative to the total level that would result with all talkers facing the same direction.

**Table 5** Approximate reduction in total sound pressure levels for group of talkers facing all directions compared to all talkers facing the same direction.

frequency	125	250	500	1000	2000	4000	8000
relative level dB	-1.2	-1.9	-1.6	-1.8	-3.6	-4.4	-5.0

## 6 Appendix: References

Research into noise source levels within/from licensed premises has been undertaken internationally, domestically, as well as in-house by AAAC Consultancies as part of many noise assessments previously conducted. References include:

- I Cushing et al - *Vocal effort levels in anechoic conditions*. Applied Acoustics vol 72 2011
- J H Rindel - *Acoustical capacity as a means of noise control in eating establishments* Presented at the Joint Baltic-Nordi Acoustics Meeting June 2012 Odense.
- J H Rindel -*The Acoustics of Places for Social Gatherings* Presented at EuroNoise 2015 Maastricht
- J H Rindel *Verbal communication and noise in eating establishments* Applied Acoustics 71 (2010)
- M Hayne et al– *Prediction of Noise from Small to Medium Sized Crowds* – AAS Paper Number 133 presented at AAS Conference November 2011
- Publication – *Noise from Pubs and Clubs Phase 1* – W. J. Davis et al – October 2005
- Publication – *New Orleans Sound Ordinance and Soundscape – Evaluation of Recommendations* – David S. Woolworth – August 2013

**Other Published AAAC Guidelines:**

AAAC Guideline for Apartment and Townhouse Acoustic Rating

AAAC Guideline for Child Care Centre Acoustic Assessment

AAAC Guideline for Commercial Building Acoustics

AAAC Guideline for Educational Facilities Acoustics

AAAC Guideline for Report Writing

AAAC Guideline for Selection of an Acoustical Consultant

For definition of terms, see the Terminology Tabs on the AAAC website.

Version	Date
1.0	August 2019